

# Courtyard Optional Screen

## Installation Instructions

### Models: SCN-ODCOUG36 and

#### **SCN-ODCOUG42**

For use with Courtyard Outdoor Gas Appliance.

KIT	UNIT
SCN-ODCOUG36	ODCOUG-36
SCN-ODCOUG42	ODCOUG-42

#### **Before You Start**

This optional screen allows a layer of protection for your outdoor gas appliance from leaves, branches and other large debris and is designed to be left in place during operation. Read instructions completely before installing optional screen. This screen can be installed easily after unit installation or at any time after.

#### KIT CONTENTS:

Screen	One (1)
Canopy	.One (1)




Figure 1. Installing the Screen

#### **ACAUTION!**

Allow gas appliance to cool completely before attempting to install or remove screen.

#### **Installation Instructions**

- 1. Inspect screen for any damage.
- 2. Locate the two(2) screws holding the mesh screen rods in place and remove. Note: The mesh screens and rods cannot be used with the optional screen kit.
- **3.** Locate the five(5) screws securing the eyebrow in place to the top of the inner firebox and remove.
- **4.** Replace the eyebrow with the supplied canopy from the optional screen kit and secure with screws from the eyebrow.
- 5. Locate the tabs on the top and bottom of the screen. The top two(2) tabs are smooth. The bottom three (3) tabs each have shoulders. Shown in Figure 2.
- **6.** Locate the five(5) slots inside the unit (2 on top and 3 on bottom.)
- 7. Insert the top tabs of the screen into the top slots of the inner firebox lifting up until the screen collides with inner firebox celing. Shown in Figure 1.
- 8. Align the three(3) tabs on the bottom of the screen with the three(3) slots located on the lower front firebox opening and lower into place. The shoulders on the lower tabs will hold the proper spacing evenly around the entire opening. Installation is complete.
- 9. To remove, lift from the bottom of the screen directly up and pull out to clear firebox bottom. Carefully lower until top tabs are no longer engaged and remove.




Figure 2. Screen Tabs

Outdoor Lifestyles, a brand of Hearth & Home Technologies 7571 215th Street West, Lakeville, MN 50044 www.hearthnhome.com